

INDEX

Emulator	Page
E1	On-chip Debuggers Performance Property - 1
E20	On-chip Debuggers Performance Property - 2
MINICUBE2	On-chip Debuggers Performance Property - 3
E10A-USB	On-chip Debuggers Performance Property - 4, 5
E8a	On-chip Debuggers Performance Property - 6

E1 Debugging Function

Target MCU			Connection system	Break Function			Trace Function	Memory reference & change while executing program	Performance measurement	Hot plug-in		
Family	Series/Core	Group		Hardware Break	Software Break	Special Break					Internal trace	
RH850	RH850/F1x	RH850/F1L	LPD4-pin or LPD1-pin	12 points being shared by an execution address and data access	Not settable for ROM area 2000 points for RAM area		Between 2K and 4K of branch information can be acquired when this is the only target or Between 1K and 2K of cycle information on data-access operation can be acquired when this is the only target		Supported	Not supported		
RL78	RL78/D1x	RL78/D1A	Single-wire Serial	1 point being shared by an execution address and data access	2000 points	Forcible break by selecting "Stop" on emulator debugger	Not supported	Supported	Not supported; the time b/w Go and Stop is measurable.	Supported *5		
	RL78/F1x	RL78/F12		2 points being shared by an execution address and data access			Not supported					
		RL78/F13 RL78/F14		2 points for an execution address	Not supported							
	RL78/G1x	RL78/G10		RL78/G14 (ROM: 96KByte and more)	2 points being shared by an execution address and data access		2000 points				Not supported	Obtains the information of up to 256 branches (only branch-source info); the obtainable info is limited to 64 branches on some MCUs.
		RL78/G12 RL78/G13 RL78/G14 (ROM: 64KByte and less) RL78/G1A RL78/G1C		RL78/G1A RL78/G1C	1 point being shared by an execution address and data access						Not supported	Obtains the information of up to 256 branches (only branch-source info)
				RL78/L1x	RL78/L1A						1 point being shared by an execution address and data access	Not supported
		RL78/L12 RL78/L13		RL78/L1C	2 points being shared by an execution address and data access						Not supported	Obtains the information of up to 256 branches (only branch-source info)
RX	RX600	RX64M	JTAG or Single-wire Serial	8 points for an execution address + 4 points for a data access (DMAC or DTC bus is selectable as a bus master) * Sequential breaks are specifiable.	256 points at the max	Forcible break by selecting "Stop" on emulator debugger	Obtains the information of up to 256 branches or the information of up to 256 cycles on data-access operation (DMAC or DTC bus is selectable as a bus master)	Supported	Supported *5 *6			
		Others than RX64M	JTAG or double-wire Serial *4 (clock and data)	8 points for an execution address + 4 points for a data access * Sequential breaks are specifiable.			Obtains the information of up to 256 branches or the information of up to 256 cycles on data-access operation					
	RX200	Single-wire Serial	4 points for an execution address + 2 points for a data access * Sequential breaks are specifiable.	Obtains the information of up to 64 branches or the information of up to 64 cycles on data-access operation *3								
	RX100		Obtains the information of up to 32 branches or the information of up to 32 cycles on data-access operation									
V850 *1 *2	V850E1 V850ES V850E2	JTAG, double-wire or 4-wire Serial (data x 2, clock and handshake)	2 points being shared by an execution address and data access * Sequential breaks are specifiable.	4 points for ROM area 2000 points for RAM area	Not supported	Forcible break by selecting "Stop" on emulator debugger	Not supported	Supported *5				
	V850E2M V850E2S	Nexus or Single-wire Serial	[When using JTAG I/F] Before-execution: 4 points After-execution: 8 points Access: 6 points * Sequential breaks are specifiable.	[When using Serial I/F] Before-execution: 4 points After-execution: Not supported Access: 4 points * Sequential breaks are specifiable.					8 points for ROM area 2000 points for RAM area			
78K0R				1 point being shared by an execution address and data access	2000 points		Not supported		Not supported; the time b/w Go and Stop is measurable.			
78K0			double-wire Serial (clock and data)	1 point for a before-execution break (only when software breaks are not used) + 1 point for Access break	2000 points		Not supported					
R8C	R8C/Lx	Single-wire Serial	8 points for an address break + 2 points for a data condition break * Sequential breaks are specifiable.	256 points at the max	256 points at the max	Forcible break by selecting "Stop" on emulator debugger	Obtains the information of 4 branches (sum of the branch-source and branch-destination PC) or the information of up to 8 cycles of specified data access	Not supported	Not supported			
	R8C/5x											
	R8C/3xT-A											
	R8C/3x											

Notes:
 *1. V850E2/ME3 and V850E/ME2 cannot be used with the E1 emulator. Use the MINICUBE for them.
 *2. The number of break points varies by the integrated development environment you use.
 *3. For RX220 group, the information of 32 branches or the information of 32 cycles on data-access operation is obtained.
 *4. The debugging function and the connection system vary by the MCU you use.
 *5. Hot-plug Adapter for the E1 Emulator (optional) is required.
 *6. Available only when the emulator is connected via JTAG interface.

* The information provided only applies to MCUs where we have been able to confirm the specifications of the emulator. This includes MCUs and emulator software that are under development. For more information on support for these items as it becomes available, check our website at: <http://www.renesas.com/e1/devices>

E20 Debugging Function

Target MCU			Connection system	Break Function			Trace Function		Memory reference & change while executing program	Performance measurement	Real-time RAM monitor	CO coverage	Hot plug-in				
Family	Series/Core	Group		Hardware Break	Software Break	Special Break	Internal trace	External Trace									
RH850	RH850/F1x	RH850/F1L	LPD4-pin or LPD1-pin	12 points being shared by an execution address and data access	Not settable for ROM area 2000 points for RAM area		Between 2K and 4K of branch info can be acquired when this is the only target or Between 1K and 2K of cycle info on data-access operation can be acquired when this is the only target	Not supported	Supported			Not supported					
RL78	RL78/D1x	RL78/D1A	Single-wire Serial	1 point being shared by an execution address and data access	2000 points	Forcible break by selecting "Stop" on emulator debugger	Not supported	Not supported	Not supported; the time b/w Go and Stop is measurable.	Not supported	Not supported	Not supported					
	RL78/F1x	RL78/F12		2 points being shared by an execution address and data access			Obtains the information of up to 128 branches (only branch-source info); the obtainable info is limited to 64 branches on some MCUs.										
		RL78/F13 RL78/F14		2 points for an execution address	Not supported												
	RL78/G1x	RL78/G10		2 points being shared by an execution address and data access	Obtains the information of up to 256 branches (only branch-source info)												
		RL78/G14 (ROM: 96KByte and more)		1 point being shared by an execution address and data access	Not supported												
		RL78/G12 RL78/G13 RL78/G14 (ROM: 64KByte and less) RL78/G1A RL78/G1C			Not supported												
	RL78/I1x	RL78/I1A		1 point being shared by an execution address and data access	2000 points		Not supported	Not supported					Not supported	Not supported	Not supported	Not supported	Not supported
	RL78/L1x	RL78/L12 RL78/L13		2 points being shared by an execution address and data access													
				RL78/L1C	1 point being shared by an execution address and data access												
	RX	RX600		RX64M	JTAG or Single-wire Serial		8 points for an execution address + 4 points for a data access (DMAC or DTC bus is selectable as a bus master) * Sequential breaks are specifiable.	256 points at the max						Obtains the information of up to 256 branches or the information of up to 256 cycles on data-access operation (DMAC or DTC bus is selectable as a bus master)	Obtains the information of approx. 2M branches or the information of approx. 2M cycles on data access operation (DMAC or DTC bus is selectable as a bus master)	Supported	Supported
Others than RX64M			JTAG or double-wire Serial *4 (clock and data)	8 points for an execution address + 4 points for a data access * Sequential breaks are specifiable.	Obtains the information of up to 256 branches or the information of up to 256 cycles on data-access operation	Obtains the information of approx. 2M branches or the information of approx. 2M cycles on data access operation											
RX200		Single-wire Serial	4 points for an execution address + 2 points for a data access * Sequential breaks are specifiable.	Obtains the information of up to 64 branches or the information of up to 64 cycles on data-access operation *3	Not supported												
RX100			Obtains the information of up to 32 branches or the information of up to 32 cycles on data-access operation	Not supported													
V850 *1 *2	V850E1 V850ES V850E2	JTAG, double-wire or 4-wire Serial (data x 2, clock and handshake)	Nexus or Single-wire Serial	2 points being shared by an execution address and data access * Sequential breaks are specifiable.	4 points for ROM area 2000 points for RAM area		Not supported	Not supported	Not supported; the time b/w Go and Stop is measurable.	Not supported	Not supported	Supported					
	V850E2M V850E2S	[When using JTAG I/F] Before-execution: 4 points After-execution: 8 points Access: 6 points * Sequential breaks are specifiable.		[When using Serial I/F] Before-execution: 4 points After-execution: Not supported Access: 4 points	8 points for ROM area 2000 points for RAM area												
78K0R			double-wire Serial (clock and data)	1 point being shared by an execution address and data access	2000 points		Not supported	Not supported									
78K0				1 point for a before-execution break (only when software breaks are not used) + 1 point for an access break	2000 points												
R8C	R8C/Lx	Single-wire Serial		8 points for an address break + 2 points for a data condition break * Sequential breaks are specifiable.	256 points at the max		Obtains the information of 4 branches (sum of the branch-source and branch-destination PC) or the information of up to 8 cycles of specified data access	Not supported				Not supported					
	R8C/5x																
	R8C/3xT-A																
	R8C/3x																

Notes:
 *1. V850E2/ME3 and V850E/ME2 cannot be used with the E1 emulator. Use the MINICUBE for them.
 *2. The number of break points varies by the integrated development environment you use.
 *3. For RX220 group, the information of 32 branches or the information of 32 cycles on data-access operation is obtained.
 *4. The debugging function and connection system vary by the MCU you use.
 *5. Available only when the emulator is connected via JTAG interface.

* The information provided only applies to MCUs where we have been able to confirm the specifications of the emulator. This includes MCUs and emulator software that are under development. For more information on support for these items as it becomes available, check our website at: <http://www.renesas.com/e20/devices>

MINICUBE2 Debugging Function

Target MCU			Break Function			RAM Monitor	DMM (Rewriting memories during RUN)	Time Measurement (from the start of execution to break)
Family	Series / Core	Group	Hardware Break	Software Break	Forcible break			
V850	V850E1 V850ES V850E2		2 points *1 (Shared by an execution and access)	ROM area: 4 points RAM area: 2000 points	Supported *2	Supported	Supported	Measurement resolution: 100 μs Max. measurement time: Approx. 100 hours
	V850E2M V850E2S		Before-execution break : 4 points Access break : 4 points * Sequential breaks are specifiable.	ROM area: 8 points RAM area: 2000 points	Supported			
78K0R			1 point (Shared by an execution and access)	2000 points	Supported	Pseudo-Real RAM Monitor (RRM) : Supported	Supported	Measurement resolution: 100 μs Max. measurement time: Approx. 100 hours
78K0			Before-execution break : 1 point (Not supported when software breaks are used) Access break : 1 point	2000 points	Supported	Pseudo-Real RAM Monitor (RRM) : Supported	Supported	Measurement resolution: 100 μs Max. measurement time: Approx. 100 hours
78K0S			Not supported	2000 points	Supported (Not supported while interrupts are inhibited)	Not supported	Not supported	Measurement resolution: 100 μs Max. measurement time: Approx. 100 hours

Notes:

*1. The following MCUs have not been supported yet: V850ES/KE2, V850ES/KF2, V850ES/KG2, μPD70F3733, and V850ES/IE2.

*2. A forcible break is not possible in the following states.

- Interrupts are inhibited (DI).
- Interrupts from the serial interface used for communications between MINICUBE2 and the target device are masked.
- The device is on standby and triggering of release from standby by makeable interrupts is disabled.
- The main clock is stopped while the UART is being used as the communications interface between MINICUBE2 and the target device.

* The information provided only applies to MCUs where we have been able to confirm the specifications of the emulator.

This includes MCUs and emulator software that are under development. For more information on support for these items as it becomes available, check our website at:

<http://www.renesas.com/cubesuite+> > "Functions Supported by CubeSuite+" (PDF)

E10A-USB (HS0005KCU01H/HS0005KCU02H) Debugging Function

Target MCU			Break Function		Performance Measurement Function	Invalid External extension Mode of Embedded ROM	Trace Function		
Family	Series/ Core	Group	Hardware Break	Software Break			Internal Trace	AUD Trace	
SuperH	SH-4A (Except for Multi-core MCUs)		Address/Data/R/W/Execution-count condition break : 2 points + Address/R/W condition break : 4 points + Data/R/W condition break : 2 points + System bus condition break : 2 points * Sequential breaks are specifiable.		255 points	Supported	No Mode	8 branches Up to 64K events *1 (Up to 32K of branch information can be acquired when branch trace is the only target)	
	SH-4	SH7760 SH7751R	Address/Data/R/W : 2 points + Address/R/W condition break : 4 points * Sequential breaks are specifiable.			Supported	No Mode	8 branches Up to 64K events *1 (Up to 32K of branch information can be acquired when branch trace is the only target)	
		SH7750R					No Mode	-	
	SH-3	SH7721 SH7720 SH7712 SH7710 SH7705	Address/Data/R/W/Execution-count condition break : 1 point + Address/R/W condition break : 1 point * Sequential breaks are specifiable.			Supported	No Mode	8 branches Up to 64K branches *1 (Only branch-destination information)	
		SH7727 SH7709S SH7706					No Mode	Up to 26214 branches *1	
	SH-2A (Except for Multi-core MCUs)	SH7206					No Mode		
		SH72AY SH72AW SH72A0 SH72A2					No Mode	1000 cycles	
		SH7211 SH7216 (SH7216, SH7214) SH7231 SH7237 SH7239 SH7243 SH7285 SH7286		Address break : 8 points + Address/Data/R/W/Execution-count condition break : 1 point + Address/Data/R/W condition break : 1 point * Sequential breaks are specifiable.		Supported	Supported	Select the target info from: Address/Data/Status/ Time stamp bus. Up to 64K events *1 (Up to 32K of branch information can be acquired when branch trace is the only target)	
		SH7670 SH726A SH726B SH7269 SH7268 SH7267 SH7266 SH7264 SH7262 SH7203 SH7263					No Mode	256 cycles Select the target info from: Address/Data/Status/ Time stamp bus.	
		SH7201 SH7261					No Mode		
		SH726R SH7254R					Supported	-	
		SH7253					No Mode	-	
		SH7619 SH7618		Address/Data/R/W/Execution-count condition break : 1 point + Address/R/W condition break : 1 point * Sequential breaks are specifiable.			No Mode	4 branches	
		SH7145F SH7144F SH7047F		Address break : 4 points * Sequential breaks are specifiable.			-	-	
		R5F71494A R5F71464A R5F70865A R5F70855A R5F70854A R5F70845A R5F70844A R5F70835A R5F70834A		Address break : 2 points + Address/Data/R/W/Execution-count condition break : 1 point + Address/Data/R/W condition break : 1 point * Sequential breaks are specifiable.		Supported	Supported	4 branches	
		SH7137 SH7136 SH7125 SH7124					Supported		
		R5E71494R R5E71491R R5E71464R R5E70865R R5E70855R R5E70845R R5E70835R		Address break : 8 points + Address/Data/R/W/Execution-count condition break : 1 point + Address/Data/R/W condition break : 1 point * Sequential breaks are specifiable.		Supported	Supported	1000 cycles Select the target info from: Address/Data/Status/ Time stamp bus. Up to 64K events *1 (Up to 32K of branch information can be acquired when branch trace is the only target)	
	H8SX	H8SX/1700	H8SX/1720S H8SX/1720	Address break : 3 points + Address/Data/Satisfaction-count condition break : 1 point * Sequential breaks are specifiable.		Supported	- *3	8 branches	
		H8SX/1600							
		H8SX/1500							
H8S	H8S/2400	H8S/2472 H8S/2463 H8S/2462				-	4 branch sources		
		H8S/2456R H8S/2456 H8S/2454 H8S/2426R H8S/2426 H8S/2424	Address break : 6 points + Address/Data condition break : 2 points		Supported	Supported	4 branch sources or Bus trace : 1024 cycles		
		H8S/2427R H8S/2427 H8S/2425					8 branch sources		
		H8S/2378							
	H8S/2300	H8S/2378R H8S/2368 H8S/2319 *4 H8S/2339 *5 H8S/2329 *6	Address/Data condition break : 2 points			-	4 branch sources or Bus trace : 512 cycles		
		H8S/2218 H8S/2215 *7 H8S/2212	Address/Data condition break : 2 points			Supported	4 branch sources		
	H8S/2200				-	-	4 branch sources		

Notes:
*1. Not usable with HS0005KCU01H.
*2. Not usable with HS0005KCU01H. While using RAM monitor function with HS0005KCU02H, no trace information can be acquired.
*3. Supported only by H8SX/1651.
*4. Only H8S/2319EF is supported.
*5. Only H8S/2339EF is supported.
*6. Only H8S/2329EF is supported.
*7. Only H8S/2215R and H8S/2215T are supported.

Acquirable trace information:
Branch, Memory access within the specified range, and Software trace (Trace(x): variable x).
* The information provided only applies to MCUs where we have been able to confirm the specifications of the emulator. This includes MCUs and emulator software that are under development. For more information on support for these items as it becomes available, check our website at: http://www.renesas.com/e10a_usb/devices

E10A-USB (HS0005KCU01H/HS0005KCU02H) Debugging Function - Continued-

Target MCU			Break Function		Performance Measurement Function	Invalid External extension Mode of Embedded ROM	Trace Function	
Family	Series/ Core	Group	Hardware Break	Software Break			Internal Trace	AUD Trace
H8S	H8S/2100	H8S/2168 H8S/2153 H8S/2164 H8S/2117 H8S/2117R H8S/2125 H8S/2116 H8S/2113 H8S/2112 H8S/2112R	Address break : 6 points + Address/Data condition break : 2 points	255 points	Not supported	No Mode	4 branch sources	Not supported
		H8S/2189R H8S/2114R	Address break : 6 points + Address/Data condition break : 2 points				4 branch sources or Bus trace : 512 cycles	

- Notes:
 *1. Not usable with HS0005KCU01H.
 *2. Not usable with HS0005KCU01H. While using RAM monitor function with HS0005KCU02H, no trace information can be acquired.
 *3. Supported only by H8SX/1651.
 *4. Only H8S/2319EF is supported.
 *5. Only H8S/2339EF is supported.
 *6. Only H8S/2329EF is supported.
 *7. Only H8S/2215R and H8S/2215T are supported.

* The information provided only applies to MCUs where we have been able to confirm the specifications of the emulator. This includes MCUs and emulator software that are under development. For more information on support for these items as it becomes available, check our website at:
http://www.renesas.com/e10a_usb/devices

E10A-USB (HS0005KCU01H/HS0005KCU02H + Debug MCU Board) Debugging Function

Target MCU			Break Function		Performance Measurement Function	Invalid External extension Mode of Embedded ROM	Trace Function	
Family	Series/ Core	Group	Hardware Break	Software Break			Internal Trace	AUD Trace
SuperH	SH-4A	SH7456 SH7455 SH7451 SH7450	Address/Data/R/W/Execution-count condition break : 2 points + Address/R/W condition break : 4 points + Data/R/W condition break : 2 points + System bus condition break : 2 points * Sequential breaks are specifiable.	255 points	Supported	No Mode	8 branches	Up to 64K events *1 (Up to 32K of branch information can be acquired when branch trace is the only target.)
		SH7125 SH7124	Address break : 8 points + Address/Data/R/W/Execution-count condition break : 1 point + Address/Data/R/W condition break : 1 point * Available to specify the sequential break				1000 cycles Select the target one from Address/Data/Status/Time stamp bus.	Up to 64K events *1 (Up to 32K of branch information can be acquired when branch trace is the only target.)
H8S	H8S/2400	H8S/2456R H8S/2456 H8S/2454 H8S/2426R H8S/2426 H8S/2424	Address break : 6 points + Address/Data condition break : 2 points		Not supported	Supported	4 branch sources or Bus trace : 1024 cycles	Not supported

- Note:
 *1. Not usable with HS0005KCU01H.
 Acquirable trace information: Branch, Memory access within the specified range, and Software trace (Trace(x): variable x).

E10A-USB (HS0005KCU14H) Debugging Function

Target MCU			Break Function		Performance Measurement Function	Invalid External extension Mode of Embedded ROM	Trace Function	
Family	Series/ Core	Group	Hardware Break	Software Break			Internal Trace	AUD Trace
SuperH	SH-4A (Multi-core MCU)	SH7786	10 points (Using UBC module)	255 points (for each core in MCU)	Supported	No Mode	60 sets of branch sources and destinations	Up to 128K events (Up to 64K of branch information can be acquired when branch trace is the only target.)
	SH-2A (Multi-core MCU)	SH7205 SH7265					1024 cycles (When acquiring trace info by core in MCU, 512 cycles respectively.)	

Acquirable trace acquisition information: Branch, Memory access, and General register. (Conditions are settable by each CPU.)

■ E8a Debugging Function

Target MCU			Break Function			Trace Function		
Family	Series/ Core	Group	Hardware Break	Software Break	Special Break	Internal Trace		
R8C	R8C/Lx		Address break : 8 points + Data condition break : 2 points * Sequential breaks are specifiable.	255 points	Forcible break by selecting "Stop" on emulator debugger	4 branches (sum of branch source PC and destination PC) or Up to 8 cycles of specified data access		
	R8C/Mx		Address break : 4 points + Data condition break : 1 point			3 branches (sum of branch source PC and destination PC) or 6 branches (branch source PC) or Up to 8 cycles of specified data access		
	R8C/3x	Other than R8C/3xD	Address break : 8 points + Data condition break : 2 points * Sequential breaks are specifiable.			4 branches (sum of branch source PC and destination PC) or Up to 8 cycles of specified data access		
		R8C/3xD	Address break : 4 points or Address break : 2 points + Data condition break : 1 point			The latest 4 branches (branch source PC)		
	R8C/2x							
	R8C/1x	Other than R8C/10-13	Address break : 2 points			-		
R8C/10-13		-						
M16C	R32C/100		Address break : 8 points			255 points	Forcible break by selecting "Stop" on emulator debugger	-
	M32C/80							-
	M16C/60	M16C/62P M16C/6Nx M16C/6S M16C/63 M16C/64A M16C/64C M16C/65 M16C/65C M16C/6C	Address break : 8 points + Data condition break : 2 points * Sequential breaks are specifiable.					32 branches of order execution history (sum of branch source PC and destination PC) or Up to 64 cycles of specified data access
				16 branches of order execution history (sum of branch source PC and destination PC) or Up to 32 cycles of specified data access				
				32 branches of order execution history (sum of branch source PC and destination PC) or Up to 64 cycles of specified data access				
				-				
M16C/50		Address break : 6 points	The latest 8 branch sources or The latest 4 branch sources + 4 branch destinations					
M16C/Tiny			-					
H8S	H8S/Tiny		Address break : 8 points + Address/Data condition break : 2 points	255 points	Forcible break by selecting "Stop" on emulator debugger			The latest 4 branch sources
H8	H8/300H Tiny		Address/Data condition break : 1 point					
	H8/300H Super Low Power		Address break : 1 point + Address/Data condition break : 1 point					
	H8/300L Super Low Power		Address/Data condition break : 1 point					
740			Address break : 2 points	-				

* The information provided only applies to MCUs where we have been able to confirm the specifications of the emulator.
This includes MCUs and emulator software that are under development. For more information on support for these items as it becomes available, check our website at:
<http://www.renesas.com/e8a/devices>