



Push-Fit Control Knobs—Two Piece

P102

Push-on version of the 10 mm collet knob series.



H 0/9 D4 W



P138

Single-color standard knob. Can be used as the top section with P139 to make a dual-concentric pair.



H 0 or 8/9 D6 or S6 N, S, or W



P150

Push-on version of the 15 mm collet knob series.



H 0/9 D025 N, S, or W



P859

15 mm low-cost control knob.


H 0/NA D4, D6 or S6 N/A



P860

29 mm low-cost control knob.



H 0/NA D6 or D025 N/A



P861

19 mm low-cost control knob.



H 0/NA D6, D025 or S6 N/A



P862

19 mm control knob with screw fixing.


H 0/NA R025, R6 or R4 (Screw fit) N/A



P890

Low-profile 19 mm low-cost control knob.

H 0/NA D6 or S6 N/A



Ordering information for caps is on page 7.

Key: Knob, Slider and Button Options

Surface Material

H= Hard Nylon

S= Soft Touch

Colors


CM	CS	0	1	2	3	4	5	6	7	8	9	10
Chrome Matt	Chrome Shiny	Black	Beige	Red	Orange	Yellow	Green	Blue	Violet	Grey	White	Opaque

Knobs


Sliders

Buttons

Knob Fittings



Slider Fittings



Switch Button Fittings

28 = 2.8 mm

33 = 3.3 mm



Orientation

N=North

S=South

W=West

N=North (Dual Concentric Fit)

Viewed from underside



Part Number Info

P	300	H or S	Body/Line/Cap	Fitting	N, S or W
---	-----	--------	---------------	---------	-----------

Type Style Surface Material Colors Fitting Orientation

P	XXX	X	XX(X)	XX	X
---	-----	---	-------	----	---

e.g.: P300 H 092 D6 W

B= Button
C= Collett
F= Flexi-fit
P= Push on
S= Slider
T= Top (cap)

Other fit and custom color combinations are available to special order. Printing options are also available for buttons and sliders (see inside front cover for additional information). All special orders are subject to minimum order quantity. Contact factory or sales representative for details.