

EM60000 Tone library list

1.Instrument:

MIDI No	Instrument Name	Envelope Type	Pitch Scale	
000	Acoustic Grand Piano	0	4,5,6	
001	Bright Acoustic Piano	0	4,5,6	
002	Electric Grand Piano	0	4,5,6	
003	Honky-Tonk Piano	0	4,5,6	
004	Rhodes Piano	0	4,5,6	
005	Chorused Piano	0	4,5,6	
006	Harpsichord	0	4,5,6	
007	Clavinet	0	4,5,6	
008	Celesta	0	4,5,6	
010	Music Box	0	4,5,6	
011	Vibraphone	1	4,5,6	
012	Marimba	1	4,5,6	
013	Xylophone	1	4,5,6	
015	Ducimer	1	4,5,6	
017	Percussive Organ	2	4,5,6	
018	Rock Organ	2	4,5,6	
019	Church Organ	2	4,5,6	
020	Reed Organ	2	4,5,6	
021	Accordion	2	4,5,6	
022	Harmonica	0	4,5,6	
023	Tango Accordion	2	4,5,6	
024	Acoustic Nylon Guitar	1	4,5,6	
025	Acoustic Steel Guitar	1	4,5,6	
026	Electric Jazz Guitar	1	4,5,6	
027	Electric Clean Guitar	1	4,5,6	
028	Electric Muted Guitar	1	4,5,6	
029	Overdriven Guitar	1	4,5,6	
030	Distortion Guitar	2	4,5,6	
031	Guitar Harmonics	1	4,5,6	
033	Electric Bass Fingered	1	4,5,6	
034	Electric Bass Picked	1	4,5,6	
036	Slap Bass 1	1	4,5,6	
037	Slap Bass 2	1	4,5,6	
038	Synth Bass 1	1	4,5,6	
039	Synth Bass 2	1	4,5,6	
040	Violin	2	4,5,6	

MIDI No	Instrument Name	Envelope Type	Pitch Scale	
041	Viola	2	4,5,6	
043	Contrabass	2	4,5,6	
044	Tremolo Strings	2	4,5,6	
045	Pizzicato Strings	1	4,5,6	
046	Harp	1	4,5,6	
056	Trumpet	2	4,5,6	
057	Trombone	2	4,5,6	
059	Mute Trumpet	2	4,5,6	
060	French Horn	2	4,5,6	
064	Soprano Sax	2	4,5,6	
066	Tenor Sax	2	4,5,6	
067	Baritone Sax	2	4,5,6	
068	Oboe	2	4,5,6	
069	English Horn	2	4,5,6	
070	Bassoon	2	4,5,6	
071	Clarinet	2	4,5,6	
072	Piccolo	2	4,5,6	
073	Flute	2	4,5,6	
074	Recorder	2	4,5,6	
075	Pan Flute	2	4,5,6	
076	Bottle Blow	2	4,5,6	
077	Shakuhachi	2	4,5,6	
078	Whistle	2	4,5,6	
079	Ocarina	2	4,5,6	
105	Banjo	1	4,5,6	

2.Percussion:

No	Instrument Name
35	Acoustic Bass Drum
36	Bass Drum
37	Side Drum
38	Acoustic Snare
39	Hand Clap
40	Electric Snare
41	Low Floor Tom
42	Closed Hi-Hat
43	High Floor Tom
44	Pedal Hi-Hat
45	Low Tom
46	Open Hi Hat
47	Low-Mid Tom
48	Hi-Mid Tom
49	Crash Cymbal 1
50	High Tom
51	Ride Cymbal 1
52	Chinese Cymbal 1
53	Ride Bell
54	Tambourine
55	Slash Cymbal
56	Cowbell
57	Crash Cymbal 2
58	Vibraslap
59	Ride Cymbal 2
60	sax
61	Low Bongo
62	Mute Hi Conga
63	Open Hi Conga
64	Low Conga
65	High Timbale
66	Low Timbale
67	High Agogo
68	Low Agogo
69	Cabasa
70	Maracas
71	Short Whistle
72	Long Whistle
73	Short Guiro
74	Long Guiro
75	Claves
76	Hi Wood Block
77	Low Wood Block
78	Mute Cuica
79	Open Cuica
80	Mute Triangle
81	Open Triangle
83	Jingle Bell

