



P.C.B. Mount Phono Jacks


N333 P.C.B. MOUNT PHONO JACK





N328-51 P.C.B. MOUNT PHONO JACK




N333-51 P.C.B. MOUNT PHONO JACK




N333-51-1 P.C.B. MOUNT PHONO JACK




N333-26 P.C.B. MOUNT RIGHT ANGLE PHONO JACK




N334-15 P.C.B. MOUNT RIGHT ANGLE PHONO JACK





N333-15 P.C.B. MOUNT RIGHT ANGLE PHONO JACK



N 342-15 P.C.B. MOUNT RIGHT ANGLE PHONO JACK




J76-100 P.C.B. SURFACE MOUNT RIGHT ANGLE PHONO JACK





P.C.B. Mount Phono Jacks


J75-2028-01 P.C.B. MOUNT PHONO JACK






WA-549-1 P.C.B. MOUNT PHONO JACK



J75-2347S P.C.B. MOUNT PHONO JACK



J75-2118 P.C.B. MOUNT PHONO JACK




J71-100 SERIES INSULATED P.C.B. MOUNT PHONO JACK


PARTNO.	COLOR
J71-100	RED
J71-100-01	WHITE
J71-100-02	YELLOW
J71-100-03	BLUE
J71-100-04	GRAY
J71-100-05	BLACK

PHONO JACKS


1233 PANEL MOUNT PHONO JACK



J75-1005 PANEL MOUNT PHONO JACK




J75-1001 PANEL MOUNT PHONO JACK




PHONO JACKS


J75-2183 PANEL MOUNT PHONO JACK




J75-1021 PANEL MOUNT PHONO JACK




J75-2295 PANEL MOUNT PHONO JACK





J75-1145-01 PANEL MOUNT PHONO JACK




J75-2330 PANEL MOUNT PHONO JACK




J75-2350 PANEL MOUNT PHONO JACK




J75-2345 PANEL MOUNT PHONO JACK




N341 HEX PANEL MOUNT PHONO JACK



1247 ROUND PANEL MOUNT PHONO JACK




N342 PANEL MOUNT PHONO JACK




CHASSIS MOUNT PHONO JACKS



1223 CHASSIS MOUNT PHONO JACK





1203 CHASSIS MOUNT PHONO JACK




N372 CHASSIS MOUNT PHONO JACK




N382 CHASSIS MOUNT PHONO JACK




1211 CHASSIS MOUNT PHONO JACK





1214 CHASSIS MOUNT PHONO JACK



1212 CHASSIS MOUNT PHONO JACK



WA586 CHASSIS MOUNT PHONO JACK



WA546-4 CHASSIS MOUNT PHONO JACK

