

COAX PATCH JACKS

J3W Shown

PATCH JACK
BNC REAR INTERFACE 50Ω RCA Center pin-.070" **J3**
 75Ω WE Center pin-.090" **J3W**

PATCH JACK
"N" 50Ω "N", RCA Center pin -.070" **J9**
 75Ω "N", WE Center pin -.090" **J9W**
 Minimum vertical/horizontal centers .875"

PATCH JACK
CRIMP 50Ω RCA Center pin-.070" **J3C-**
 75Ω WE Center pin-.090" **J3WC-**

Microswitch not available.

PATCH JACK
BNC 50Ω RCA Center pin-.070" **J10**
 75Ω WE Center pin-.090" **J10W**
 Requires special threaded panel .5-.28 UNEF-2A Contact Factory when ordering panels.

PATCH JACK
SOLDER POT 50Ω RCA Center pin-.070" **J3D**
 75Ω WE Center pin-.090" **J3WD**
 (WECo 468 type)

PATCH JACK
TNC 50Ω RCA Center pin-.070" **J5**
 75Ω WE Center pin-.090" **J5W**

J3E-1 Shown

PATCH JACK
CABLE ENTRY 50Ω RCA Center pin-.070" **J3E-**
 75Ω WE Center pin-.090" **J3WE-**

(WECo 447 type) Microswitch not available

PATCH JACK
SELF-TERMINATING BNC 50Ω RCA Center pin-.070" **J13-R**
 BNC 75Ω WE Center pin-.090" **J13W-R**
 (WECo 477B type) TNC 50Ω **J13H-R**
 TNC 75Ω TNC 75Ω **J13WH-R**

BNC
PATCH JACK 50Ω RCA Center pin-.070" **J3A**
 75Ω WE Center pin-.090" **J3WA**
 External SPDT Microswitch (125-250 VAC, 5 amps/28 VDC, 1 amp res, 3 amp. ind)

PATCH JACK
SELF-TERMINATING 50Ω RCA Center pin-.070" **J13C-R-**
 75Ω WE Center pin-.090" **J13WC-R-**
 Cable crimp: Circuit is terminated when plug is removed.

△ - Refers to Cable Group Table, see pages 68-88. Standard Panels are on page 42-45. Consult with the factory for special requirements. R = Resistance