DWG NO. 3 CCS122-I REVISIONS DESCRIPTION ECN ZONE REV. DATE APPROVED **INSTALLATION INSTRUCTIONS** 6188 N/C NEW RELEASE. 9/10/98 MCT 13277 A SEE ECN 1. BEGIN BY CUTTING THE CABLE OFF SQUARE. 7/23/01 D 8. SLIDE THE BODY OF THE CONNECTOR OVER THE END OF THE CABLE UNTIL THE NOTCH IN THE CONTACT SEATS INTO THE DIELECTRIC RIDGE 2. WHEN USING AUTOMATIC STRIPPING EQUIPMENT, STRIP CABLE INSIDE THE CONNECTOR BODY. AS SHOWN STARTING WITH L1 AND ENDING WITH L3. TAKE CARE NOT TO NICK THE CONDUCTORS WHILE STRIPPING THE ECS 025122 DIELECTRIC AND JACKET. IF AUTOMATIC STRIPPING EQUIPMENT IS NOT AVAILABLE, STRIP ONLY L1 AND L3 AND TRIM EXCESS BRAID AT STEP 10. 9. FOLD ALL THREE BRAIDS UP OVER THE NECK OF THE CONNECTOR BODY. L2 = .3110. SLIDE THE FERRULE UP OVER THE SHIELDS AND AGAINST 3. SLIDE THE FERRULE AND ADHESIVE SHRINK TUBING 2 THE CONNECTOR BODY. TRIM AWAY ANY EXCESS BRAID. CRIMP OVER THE END OF THE CABLE. THE FERRULE ONCE, NEXT TO THE BODY, USING THE M22520/5-47 DIE (A HEX) IN A M22520/5-01 TOOL FRAME, APPLY ADHESIVE HEAT SHRINK. /3 4. SOLDER THE CONTACT ONTO THE CENTER CONDUCTOR, PER MIL-STD-2000, USING 63Sn/37Pb SOLDER OR CRIMP WITH M22520/5-57 DIE (B HEX). ENSURE THE CONTACT IS NOTES BUTTED AGAINST THE CABLE DIELECTRIC. CLEAN ALL FLUX RESIDUES USING AN APPROPRIATE FLUX CLEANER. 1. ALL DIMENSIONS ARE IN INCHES. 2 ENSURE HEAT SHRINK IS INSTALLED PRIOR TO CRIMPING CONNECTOR. 3 ADHESIVE HEAT SHRINK SHOULD BE APPLIED IN ACCORDANCE WITH ECS WORK INSTRUCTION WIGOOT, CONTACT ECS FOR A COPY OF THIS WORK 5. USING TWEEZERS, FOLD THE OUTER BRAID BACK OVER INSTRUCTION. THE CABLE JACKET, LEAVING AS MUCH WEAVE AS POSSIBLE. 4 CONNECTOR DIMENSIONS ARE FOR REFERENCE ONLY / I/ | • II -5. DELETED. 6. DELETED 6. SLICE THE ALUMINUM/POLYESTER FOIL LENGTHWISE ABOUT PICTORIALS SHOW CONNECTOR INSTALLATION ON ECS 311201 CABLE. EVERY 1/8". GENTLY ROTATE PIN TO SEPARATE THE FLAT FOIL 7. WHEN INSTALLING THIS CONNECTOR ON 421201 THERE ARE ONLY BRAID AND ALUMINUM/POLYESTER FOIL FROM THE DIELECTRIC. 2 SHIELDS WHICH SHOULD BE FOLDED BACK AS SHOWN IN STEP 6 USING TWEEZERS, FOLD BACK ALUMINUM/POLYESTER FOIL AND STEP 7 WOULD BE OMITTED. OVER THE OUTER BRAID. ELECTRONIC CABLE SPECIALISTS ALL LENGTHS IN INCHES FRANKLIN, WI 53132 PHONE: (414) 421-5300 EĈS APPROVALS CUSTOMER SPECIFICATION 7. USING TWEEZERS. FOLD THE INNER BRAID BACK OVER 10/23/97 E ANDERSON THE OTHER SHIELDS, LEAVING AS MUCH WEAVE AS POSSIBLE. CHECKED BY: C STRAIGHT PLUG FOR ECS CABLE 311201, 421201 9/15/98 NOTE: DO NOT UNRAVEL DIELECTRIC WHEN PULLING DESIGNED RY BACK INNER SHIELD. SIZE CAGE CODE LEVEL PART NO. 9/10/98 B 66197 M TAUBENHEIN ENG. MICH: P JOBE

6/4/99 SCALE:

FILE NO F:\E\SPEC\CONN\INST\CCS122 SHEET: 1 OF 1